



Polycure Tips & Insights: Sanding

1. Sand thoroughly between coats to ensure sound inter-coat adhesion.
2. Always use correct sandpaper or screen back to sand the coated or uncoated timber. The wrong grit can cause scratching.
3. Ensure the sandpaper and screen backs are replaced regularly so that they continue to "cut" the raw or coated floor. If they will burnish the floor which will compromise the inter-coat adhesion between coats and result in delamination.

PLEASE CONTACT POLYURE'S TECHNICAL SERVICE DEPARTMENT OR YOUR LOCAL POLYURE ACCOUNT EXECUTIVE FOR FURTHER FREE ADVICE.

www.polycure.com.au